

BRP-Powertrain
INSTALLATION MANUAL

Chapter: 24-00-00
ELECTRIC SYSTEM

Intro

The engine is supplied with the wiring completed and ready to operate. Only the following connections to the aircraft have to be established:

- integrated generator
- external rectifier-regulator
- electronic modules
- electric starter
- start relay
- items conditional for operation like circuit breakers, ON-OFF switches, control lamps, relays, instrumentation and capacitors.

Optional extras

- external alternator (as option if the output of the integrated generator is inadequate.
- electric rev counter (accessory).
- consumer (battery).

Table of contents

This section contains information about electronic modules, electric starter and wiring diagram of the engine.

Subject	Page
Requirements for the circuit wiring Electromagnetic compatibility (EMC/EMI)	Page 3 Page 4
Technical data and connection of the electric components Integrated generator	Page 5 Page 5
Rectifier-regulator Requirements for flawless operation of the rectifier-regulator	Page 6 Page 7
Electronic modules	Page 8
Ignition switches (MAG switch) Connection Assembly of the flat pin terminal	Page 9 Page 9 Page 11
External alternator (optional extra) Technical data Connection Requirements for correct operation of the integrated rectifier-regulator	Page 13 Page 13 Page 13 Page 14
Connection of the electric rev counter (tachometer) Technical data Connection	Page 16 Page 16 Page 16

d06099.fm

BRP-Powertrain
INSTALLATION MANUAL

Subject	Page
Battery	Page 16
Capacitor (Option electrical fuel pump)	Page 16
Easy start function on the electronic module (optional)	Page 17
Wiring diagram	Page 18

BRP-Powertrain
INSTALLATION MANUAL

1) Requirements for the circuit wiring

General note

NOTICE

The connections have to be made by the aircraft manufacturer in accordance with applicable regulations and the enclosed wiring diagram.
See chap. 24-00-00 section: Switch requirements.

NOTICE

The power supply to the various consumers (e.g. battery) must be adequately protected by fuses. Using incorrectly rated fuses may result in destruction of the equipment.

Under no circumstances must consumer cables (e.g. battery) be routed alongside the ignition cable. There is a risk of electromagnetic interference or damage.

NOTICE

Do not bend, kink, pinch or otherwise improperly stress the wiring harness. Use proper routing, clamping and strain relief on wiring harnesses.

BRP-Powertrain
INSTALLATION MANUAL

1.1) Electromagnetic compatibility (EMC/EMI)

Electromagnetic interference	Electromagnetic interference (EMI) and lightning The engine complies with EMI and lightning requirements as per DO-160C, sections 18, 20-22 as detailed in the following paragraphs.
Emission	Emission Conductive radio interference: Narrowband and broadband emissions meet RTCA DO160C Section 21-2 Cat. B (AZ) requirements except in the frequency range of 150 kHz-2 MHz where emissions are up to 20 dB higher than allowable limits. Radiated radio interference: Narrowband and broadband emissions meet RTCA DO160C Section 22, item 21-6 and 21-7, Cat. B requirements except in the frequency range of 190 kHz-2 MHz where emissions are up to 35 dB higher than allowable limits. NOTE: Consult the aircraft manufacturer if further interpretation is needed. The exceeded limits do not affect the operation of the engine.
Electromagnetic compatibility	Electromagnetic compatibility (EMC) The engine complies with the electromagnetic interference and lightning strike requirements of DO-160C, section 18, 20-22 and IEC 801-2. The following EMC tests have been carried out: <ul style="list-style-type: none">- Radio frequency (RF) sensitivity (conducted)- Radio frequency (RF) sensitivity (radiated)- Audio frequency sensitivity- Lightning strike sensitivity- Conducted radio frequency (RF) interference- Radiated radio frequency (RF) interference

BRP-Powertrain
INSTALLATION MANUAL

2) Technical data and connection of the electric components


2.1) Internal generator

General note **NOTE:** Approx. 250 W AC output at 5800 rpm. For DC output in connection with rectifier-regulator. See chap. 24-00-00 section: 3).

Connection See [Fig. 1](#).
Feeding wires (1) from the generator to rectifier-regulator on left side of ignition housing.

- 2 flexible cables, 1.5 mm² yellow (in shielding metal braid)
- length approx. 660 mm (26 in.) starting from ignition housing
- with on each plug socket 6.3 x 0.8 to DIN 46247

Graphic Connection



Part	Function
1	Feeding wires (yellow)

Fig. 1

02498


d06099.fm

BRP-Powertrain

INSTALLATION MANUAL

2.2) Rectifier regulator

Type	Electronic full-wave rectifier regulator.
Output voltage	14.2 V \pm 0.3 (from 1000 \pm 250 rpm).
Current limit	Current limit: Max. 22 A.
Component temperature	Max. permissible component temperature: +80 °C (176 °F) (measured in area (1)). NOTE: The performance specifications are given for optimal cooled components. If necessary, use a separate heat sink for the rectifier regulator.
Weight	See chap. 72-00-00 section: weight.
Graphic	Connection



Part	Function
1	Area component temperature
2	Description of connections: G = yellow - from generator R = red - to battery, positive terminal B = battery positive terminal L = warning lamp circuit C = control or field circuit

Fig. 2

08631

d06099.fm

BRP-Powertrain
INSTALLATION MANUAL

2.2.1) Requirements for flawless operation of the rectifier-regulator

General note

NOTICE

The voltage difference between battery and terminal **C** of regulator should be less than 0.2 V.

Use cables in this area as short as possible and with adequate cross section.

NOTICE

Never sever connection between terminal **C** and **B** of regulator (e.g. by removal of a fuse) while the engine is running. Overvoltage and regulator damage can occur.

During engine stop break circuit between battery and terminal **C** to avoid discharge of battery! (see Fig. 11).

NOTE: A charge-indicating lamp 3 W/12 V (see Fig. 11 pos. 18) may be fitted on the instrument panel.

Body of regulator

Body of regulator must be grounded with no resistance allowed.

Fuse

The rectifier-regulator has to be protected by a slow blowing 25 A fuse.

Wire size

Wire size of the main circuit of at least 2.5 mm² (14 AWG).

Capacitor

A capacitor (see Fig. 11 pos. 14) of at least 22000 µF/25 V is necessary to protect the correct function of regulator and to flatten voltage. The regulator is not designed to store any electrical charge. If for any reason the battery or bus system is disconnected from the regulator while the engine is running (i.e. the master switch is shut off) the capacitor will safely absorb and dissipate the electrical charge produced by the generator. Otherwise the regulator would be damaged.

Amperage

NOTICE

The graph current over engine speed has been determined and is valid only at the following conditions:

- Ambient temperature: 20 °C (68 °F)
- Voltage: permanent 13.5 V
- Tolerance: max ± 5 %

BRP-Powertrain

INSTALLATION MANUAL

Graphic

Current




Fig. 3

02500

2.3) Electronic modules

See Fig. 4.

Component temperature

Component temp. for the electronic modules (1): max. 80 °C (176 °F).


BRP-Powertrain
INSTALLATION MANUAL

2.4) Ignition switches (MAG switch)

Type	Two separate, suitable on-off switches (Fig. 11 pos. 15).
Switching voltage	Min. 250 V.
Switching current	Min. 0.5 A.

2.4.1) Connection

Wires	See Fig. 4. Wires from the ignition switches connect to the electronic module (1).
Graphic	Electronic modules



Part	Function
1	Electronic modules

Fig. 4

02501

Wire	See Fig. 5.
------	-------------

NOTICE

The electromagnetic compatibility (EMC) and electromagnetic interference (EMI) depends essentially on the wire used.

Min. section area: 2x 0.75 mm² (18 AMG) (shielded flexible cable, shielding braid on both ends grounded to prevent EMI (e.g. specification MIL-27500/18).

d06099.fm

BRP-Powertrain


INSTALLATION MANUAL

NOTICE

No or insufficient shielded cables can cause engine shut-off due to electromagnetic and radio interference.

The metal base of each ignition switch must be grounded to aircraft frame to prevent EMI.

Wire A	Wire of top electronic module (marked "A") for ignition circuit A.
Wire B	Wire of bottom electronic module (marked "B") for ignition circuit B.
Ignition circuit A	NOTE: Ignition circuit A controls: top spark plugs of cylinder 1 and 2; lower spark plugs of cylinder 3 and 4.
Ignition circuit B	NOTE: Ignition circuit B controls: top spark plugs of cylinder 3 and 4; lower spark plugs of cylinder 1 and 2.
Graphic	Wire



Part	Function
1	Wire for ignition circuit A
2	Wire for ignition circuit B

Fig. 5

07602

Flexible wire

One each flexible wire 0.75 mm² (18 AMG), brown.

Length approx. 35 mm (1 3/8") beginning at electronic module with one each plug socket and insulating sleeve 3.96 mm. At the new version the cable grommet and fasten connector are integrated in the 6-pole connector housing. See also SI-912-013, latest issue.

d06099.fm

BRP-Powertrain
INSTALLATION MANUAL

2.4.2) Assembly of the flat pin terminal

General note See Fig. 6.

NOTE: One each cable grommet (1) and flat pin terminal (2) are supplied loosely packed.

Special tools The following special tools and equipment are necessary for fitting the Faston connector.

Part number	Description
n.a.	MOLEX Crimping pliers 64016-0035
n.a.	MOLEX Disassembly tool 63813-1500

Procedure Assembly of the flat pin terminal

Step	Procedure
1	Strip cable (3) as required.
2	Install the cable grommet (1) in correct position and direction (A).
3	Use suitable crimping pliers (4) to fit the faston connector (B).
4	The rubber grommet is held by the secondary crimp.
5	Push the faston connector in the corresponding slot (4) of the connector receptacle until it is locked in place (C).
6	Check for tight fit.
7	Press the pin holder (white) downwards using the long nose pliers.

NOTE: Faston connector and insulation sheath of the old version are available as spare part. See also SI-912-013, latest issue.


NOTE: The pin holder must not be pressed with excessive force.

BRP-Powertrain

INSTALLATION MANUAL

Graphic

Assembly of the flat pin terminal



Part	Function
1	Cable grommet
2	Flat pin terminal
3	Wiring (airframe)
4	Crimping pliers
5	Position in the connector housing

Fig. 6

08323

BRP-Powertrain
INSTALLATION MANUAL

2.5) External alternator (optional extra)

General note See [Fig. 7](#).

2.5.1) Technical data

General note NOTE: The voltage regulator is integrated in the alternator.

Output Output: Max. 600 W/DC at 6000 r.p.m.

Output Voltage Output Voltage: 14.2 V - 14.8 V.

Ambient temperature range Ambient temperature: Min. -30 °C (-22 °F)
Max. +90 °C (194 °F)

Weight See chap. 72-00-00 section: Technical data.

2.5.2) Connection

Power supply wires Power supply wires to external alternator (1) located on the outside of propeller gear.

Positive terminal Positive terminal (2):
- M6 screw connection suitable for cable terminal according to DIN 46225 (tightening torque 4 Nm (35 in.lb)).

Grounding Via engine block.

Control wiring Control wiring (field circuit) (3):
- Via supplied standard plug (Sumitomo 6111-2568) and 6.3 x 0.8 Fasten connectors.


d06099.fm

BRP-Powertrain

INSTALLATION MANUAL

Graphic

External alternator



Teil	Funktion
1	External alternator
2	Positive terminal
3	Control wiring

Fig. 7

03199,02764,00547

2.6) Requirements for correct operation of the integrated rectifier regulator

Fuse	The rectifier regulator must be protected by a slow blowing fuse or circuit breaker. Fuse or circuit breaker rating must be determined by load, wire size and length.
Cross section	Wire size of the main circuit at least 4 mm ² (0.006 in ²).
Capacitor	A capacitor of at least 22000 µF/25 V is necessary to flatten voltage.

d06099.fm

BRP-Powertrain

INSTALLATION MANUAL

Amperage

NOTICE

The current over speed graph was determined and is only effective under the following conditions:

- Ambient temperature: 20 °C (68 °F)
- Voltage: constant 13.5 V
- Tolerance: max. $\pm 5\%$

NOTE: The speed of the external generator is 1.24 times the crankshaft speed or 3 times the propeller speed.

Graphic




Fig. 8

00547

d06099.fm

BRP-Powertrain
INSTALLATION MANUAL

2.7) Connection of the electric rev counter (tachometer)

2.7.1) Technical data

Output signal	NOTICE	The graphs depicting output signals have been determined and are effective only at the following conditions: <ul style="list-style-type: none">- Ambient temperature: 20 °C (68 °F)- Tolerance: Max. ± 5% NOTE: The pick-up for the rev counter generates one pulse per revolution.
---------------	---------------	--

2.7.2) Connection

General note	NOTICE	BRP-Powertrain developed especially for this application a non-certified electric rev counter. Certification to the latest requirements such as FAR or EASA has to be conducted by the aircraft manufacturer. See also SI-13-1996, latest issue.
Feeding wiring	Feeding wiring to electric rev counter on left side of ignition housing. <ul style="list-style-type: none">- Length approx. 600 mm (24 in.) starting from ignition housing.	
Connections	2 flexible cables 0.5 mm ² , white/yellow and blue/yellow (in insulation wrap).	

2.8) Battery

General note	See Fig. 11.	
	NOTICE	To warrant reliable engine start use a battery of at least 16 Ah capacity.

2.9) Capacitor (Option electrical fuel pump)

General note	See Fig. 11.	
	NOTICE	To warrant reliable operation of the electrical fuel pump the use of capacitor of at least 1 µF/25 V is necessary.

BRP-Powertrain

INSTALLATION MANUAL

2.10) Easy start function on the electronic module (optional)

General note

See Fig. 10.

In order to use the easy start function the relevant connections to the starter relays and ignition switch need to be made.

The start function can be used for aircraft, which have an engine start problem in cold conditions.

NOTE: In addition also a modified fly wheel hub is offered, which aids improved starting.

Graphic

Easy start function




Fig. 10

08556

d06099.fm

BRP-Powertrain
INSTALLATION MANUAL

2.11) Wiring diagram

General note See [Fig. 11](#).

Scope of delivery

NOTICE

Items/components which are not included in the standard engine scope of delivery must be certified the aircraft or fuselage manufacturer in accordance with the latest regulation, such as FAR or EASA.


Position	Supply
1-9	Are included in the standard volume of supply of the engine.
22-24	Are included in the standard volume of supply of the engine.
10-14	Are available as accessory.
15-22	Can't be supplied by BRP-Powertrain.
25	Can't be supplied by BRP-Powertrain.

BRP-Powertrain

INSTALLATION MANUAL

Graphic

Wiring diagram



d06099.fm

Effectivity: 912 Series
Edition 2/Rev. 0

24-00-00

page 19
August 01/2012

BRP-Powertrain

INSTALLATION MANUAL

Legend to wiring diagram

Part	Function	Part	Function
1	2 Electronic modules (A and B)	17	Starter switch
2, 3	Plug connection for ignition switch	18	Control lamp
4	Integrated generator	19	Battery relay
5, 6	External regulator - rectifier with plug connections	20	Battery
7	Electric starter	21	Bus Bar
8, 9	Starter relay with plug connection	22	Capacitor 1 μ F
10, 11, 12	External alternator with connection	23	Plug connection for trigger coil assy.
13	Electric rev counter	24	Trigger coil assy. (tachometer)
14	2 capacitor 1 μ F	25	Electrical fuel pump
15	2 ignition switches	26	Starting equipment at the electronic modules
16	Masterswitch		

Fig. 11

08639

d06099.fm